

CATWALK

SPECIFICATIONS AND INSTALLATION INSTRUCTIONS



MINIMIS
WWW.MINIM.IS

MODERN NATURAL MODULAR SUSTAINABLE

RECOMMENDED TOOLS FOR INSTALLATION

RECOMMENDED TOOLS:

- EYE PROTECTION
- STURDY WORK GLOVES
- POWER DRILL
- 3/16" MASONRY BIT, MINIMUM 6" LENGTH
- 1/4" TAPCON ANCHOR, MINIMUM 2.5" LENGTH
- CARPENTER'S LEVEL, MINIMUM 2' LENGTH



FOR SAFE USE OF ELECTRIC DRILL, CONSULT
MANUFACTURER'S USER MANUAL

FOR SAFE USE OF TAPCON ANCHORS, CONSULT
MANUFACTURER'S USER MANUAL


LIFT WITH YOUR KNEES, NOT WITH YOUR BACK.

ELICIT ASSISTANCE FROM A FRIEND, TO LIFT,
CARRY, OR POSITION CATWALK MODULES.


ALWAYS WEAR EYE PROTECTION



3/16"
@ 6"+




1/4" @
2.5"+




2'+

TRANSLUCENT, UV-RESISTANT, STAIN-RESISTANT, ANTI-DERRAPANT MATERIAL @ .75" THICKNESS




CONCRETE INSTALLATION: OPTION 1




ADJUSTABLE PLATE FEET ATTACH TO CONCRETE VIA TAPCON SCREWS

CONCRETE INSTALLATION: OPTION 2



HOLES DRILLED IN CONCRETE, FLANGE NUTS ADJUST FOR HEIGHT, AND THREADED LEGS ARE EMBEDDED IN THE HOLES WITH ANCHORING EPOXY

CROSS-SECTION, CATWALK MOUNTED ON LOOSE FILL WITH CONCRETE FOOTINGS



CONSULT YOUR LANDSCAPE ARCHITECT OR SPECIALIST TO ENSURE COMPLIANCE WITH LOCAL SAFETY CODES.

WHEN CONTACTING US, PLEASE SPECIFY YOUR MOUNTING SURFACE:
SOLID (CONCRETE / WOOD)
OR
LOOSE-FILL (EARTH / STONE / GRAVEL / SAND).

CATWALK FEET WITH HEIGHT-ADJUST LEGS



SOLID SURFACE INSTALLATION




WITH PROVIDED BIT, REMOVE WALK SURFACE FROM CATWALK FRAME.

POSITION THE CATWALK PANEL TO THE DESIRED HEIGHT AND LOCATION.

MARK YOUR ANCHOR POINT THROUGH THE PRE-DRILLED HOLE OF EACH CATWALK FOOT.

SET CATWALK FRAME ASIDE.



WITH A 3/16" MASONRY BIT, DRILL A PILOT HOLE THAT IS 1/2" DEEPER THAN YOUR TAPCON ANCHOR.

I.E.: 3" TAPCON ANCHOR REQUIRES PILOT HOLE OF 3.5".

MINIMUM RECOMMENDED TAPCON ANCHOR SPECIFICATIONS:

2.5" LENGTH
1/4" THICKNESS




RE-POSITION CATWALK PANEL AND MATCH HOLE IN FOOT WITH HOLE IN FLOOR.

INSERT SHIMS TO LEVEL IF NECESSARY.

DRILL IN YOUR TAPCON ANCHOR.

DO NOT OVERTIGHTEN, AND RISK BREAKING ANCHOR



CONSULT YOUR LANDSCAPE ARCHITECT OR SPECIALIST TO ENSURE COMPLIANCE WITH LOCAL SAFETY CODES.

NOTE: CATWALK PANELS CAN BE HEAVY. EXERCISE CARE IN LIFTING AND POSITIONING PANELS. LIFT WITH YOUR KNEES. IF NECESSARY, ELICIT ASSISTANCE FROM ANOTHER PERSON FOR LIFTING AND CARRYING PANELS.

LOOSE FILL INSTALLATION



POSITION THE CATWALK PANEL TO THE DESIRED HEIGHT AND LOCATION.

MARK YOUR ANCHOR POINT THROUGH THE PRE-DRILLED HOLE OF EACH CATWALK FOOT.

SET CATWALK PANEL ASIDE.



WITH A 3/16" MASONRY BIT, DRILL A PILOT HOLE THAT IS 1/2" DEEPER THAN YOUR TAPCON ANCHOR.

I.E.: 3" TAPCON ANCHOR REQUIRES PILOT HOLE OF 3.5".

MINIMUM RECOMMENDED TAPCON ANCHOR SPECIFICATIONS:

2.5" LENGTH
1/4" THICKNESS



RE-POSITION CATWALK PANEL AND MATCH HOLE IN FOOT WITH HOLE IN FLOOR.

DRILL IN YOUR TAPCON ANCHOR.

ENSURE TAPCON ANCHOR IS SNUG IN PLACE; DO NOT OVERTIGHTEN, AND RISK BREAKING ANCHOR



COPYRIGHT 2009 MINIMIS

PROTECTED BY US & INTERNATIONAL PATENTS

